

works with
DSi XL

dreamGEAR

iSound: The New Sound
www.isound.net

20001 S. Western Avenue, Torrance CA 90501
tel: 310.222.5522 :: fax: 310.222.5577

SILVER EDITION 20 in 1 Starter Kit

20 essential items for your DSi XL

ITEM No. - DGDXL-2671

UPC - 8 45620 02671 5

COLOR - Silver

PRODUCT FEATURES

- **CHARGING DOCK:** charge and dock your DSi XL with a dock where power meets style.
- **CARRYING CASE:** offers portability along with protection.
- **USB SD CARD READER:** transfer your data to and from via USB port.
- **CAR CHARGER:** stay charged and entertained while traveling.
- **EARBUDS:** crisp and clear audio experience.
- **AUDIO SPLITTER:** Share your audio with friends.
- **3 SCREEN CLEANERS:** 1 screen cleaners and 2 micro fiber cleaning cloths keep your DSi XL shiny and smudge-free.
- **CARRY ALL TOTE BAG:** Carry everything conveniently.
- **2 SMALL PRECISION STYLUSES:** Increase gaming accuracy.
- **1 LARGE PRECISION STYLUS:** Increase comfort and convenience while gaming.
- **2 SETS of SCREEN PROTECTORS:** Keep screens new and scratch free.
- **3 GAME CASES:** Keep your games organized and protected.
- **2 WRIST STRAPS:** Protect your DSi XL from being dropped or and keep your large stylus handy.

PRODUCT PACKAGING



TRANSLATIONS

	SPANISH	FRENCH
PACKAGING	NO	NO
USER'S GUIDE	YES	YES

SHIPPING INFORMATION

	QUANTITY	WIDTH (in.)	HEIGHT (in.)	DEPTH (in.)	CUBE (ft³)	WEIGHT (lbs.)	UPC NUMBER
SINGLE	1	8.5	10	2.25	0.11	0.90	8 45620 02671 5
MASTER	8	10	11	18.5	1.18	8.95	8 45620 02671 5
INNER	4	9.25	9.75	9.75	0.51	3.95	8 45620 02671 5



*DSi XL not included

works with
DSi[®] XL

dreamGEAR[®]

iSound: The New Sound[™]
www.isound.net

20001 S. Western Avenue, Torrance CA 90501
tel: 310.222.5522 :: fax: 310.222.5577

User's Guide

20in1 Starter Kit
SILVER EDITION
USER'S GUIDE

works with
DSi[®] XL



dreamGEAR
www.dreamgear.net



PACKAGE CONTENTS:

- Charging Dock
- Carrying Case
- USB SD Card Reader
- Car Charger
- Earbuds
- Audio Splitter
- 2 Small Precision Styluses
- 1 Large Precision Stylus
- 2 Sets of Screen Protectors
- 3 Game Cases
- 2 Wrist Straps
- 3 Screen Cleaners
- Carry All Tote Bag
- User's Guide/Warranty Card
- Registration Card

Charging Dock:

1. Place DSi XL upside-down onto the charging pin on the Charging Dock.
2. Plug in the Original DSi XL AC adapter into the back of the Charging Dock.
3. To release, press down on the release button located on the front of the Charging Dock.

USB SD Card Reader:

1. Pull off the back cover of the SD Card Reader exposing the opening for an SD Card.
2. Insert an SD Card into the back of the SD Card Reader.
3. Pull off the front cover of the SD Card Reader exposing the USB plug.
4. Insert the USB plug into any powered USB port to view or transfer files.
5. After viewing or transferring files, pull the SD Card Reader from the USB port.

NOTE: Please refer to your device's User's Guide on how to safely remove the SD Card Reader.

6. Pull out the SD Card from the SD Card Reader.
7. Insert the SD Card into the DSi XL.

NOTE: SD Card not included.

Car Charger:

1. Connect the Car Charger to the DSi XL's DC input.
2. Plug the Car Charger into your car's power outlet. The DSi XL will begin charging automatically.

Earbuds:

1. Insert the 3.5mm end of the Earbuds into the headphone jack located on the DSi XL.
2. Volume is adjusted by the volume control on the DSi XL.

Audio Splitter:

1. Connect the Audio Splitter to the headphone input on the DSi XL.
2. Connect up to 2 earbuds or headphones to the Audio Splitter using the 3.5mm headphone jack.

Precision Stylus:

1. Lightly touch or slide the Small Precision Stylus across the touch screen of the DSi XL.
2. Use the stylus only on the lower touch screen.
3. Use only enough pressure to operate the game. Excessive pressure may damage the touch screen.

NOTE: Do not use the stylus if it is broken. Replace the stylus in the stylus holder located on the right side of the DSi XL when not in use.

Screen Protector:

1. Peel the top off the Screen Protector by pulling the red and white sticker to the right.
2. Once you peel the Screen Protector apart, the part with the red and white sticker belongs on the screen.
3. The sticky part of the side that you place onto the screen.

dreamGEAR
www.dreamgear.net

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net