

works with
Wii

works with
MotionPLUS™

dreamGEAR

iSound: The New Sound

www.dreamGEAR.net | www.iSound.net
20001 S. Western Avenue, Torrance, CA 90501
tel: 310.222.5522 :: fax: 310.222.5577

5 in 1 Sports Essentials Plus

Glow Saber, Archery, Golf, Tennis, Remote Cradle

ITEM No. - DGWII-3136

UPC - 8 45620 03136 8

COLOR - Black

PRODUCT FEATURES

REMOTE CRADLE

- Designed for use with or without MotionPlus™
- Rubberized for comfort and control
- Fits Wii Remote with Wii Remote Jacket
- For use with Golf, Tennis, and Glow Saber attachments (*not with Archery*)

GLOW SABER

- "Easy-On" Power Button
- Fits the Wii Remote with or without MotionPlus™
- Perfect for slashing games
- Hinge design for infrared pass-through port
- LEDs for amazing glow effects
- Rubberized for comfort and control
- Fits Wii Remote with Wii Remote Jacket

ARCHERY

- Designed for use with MotionPlus™
- Adds realism to Archery games
- Infrared pass-through port
- Designed with pull-back string
- Rubberized for comfort and control
- Fits Wii Remote with Wii Remote Jacket

GOLF

- Fits the Wii Remote with or without MotionPlus™
- Adds realism to golf games
- Hinge design for infrared pass-through port
- Rubberized for comfort and control
- Fits Wii Remote with Wii Remote Jacket
- Designed using soft and safe material

TENNIS

- Fits the Wii Remote with or without MotionPlus™
- Adds realism to tennis games
- Hinge design for infrared pass-through port
- Rubberized for comfort and control
- Fits Wii Remote with Wii Remote Jacket
- Designed using soft and safe material

PRODUCT PACKAGING



TRANSLATIONS

PACKAGING | FRENCH: No | SPANISH: No
USER GUIDE | FRENCH: Yes | SPANISH: Yes

SHIPPING INFORMATION

	QUANTITY	WIDTH (in.)	HEIGHT (in.)	DEPTH (in.)	CUBE (ft³)	WEIGHT (lbs.)	UPC NUMBER
MASTER	4	11.75	18	14	1.71	8.05	8 45620 03136 8
INNER	N/A	N/A	N/A	N/A	N/A	N/A	N/A
SINGLE	1	11.25	17.5	3.25	0.37	1.70	8 45620 03136 8

RUBBERIZED SURFACE
FOR BETTER COMFORT AND CONTROL!

ARCHERY

TENNIS

GLOW SABER

GOLF

REMOTE CRADLE

Infrared Pass-through

Allows you to access the Wii Remote's infrared functionality without removing your Wii Remote from the cradle.

Glow Saber requires 2 AAA batteries (not included)
Wii Remote, Wii Remote Jacket, Nunchuk™ and MotionPlus (not included)

Sports Essentials PLUS is for use with Wii games and is not intended to be used for any other activities. Please allow for the appropriate distance between players and/or objects to avoid damage or injury. dreamGEAR LLC is not liable for damaged property or injury sustained while using this product.